




2




8



6



1



9

SU4-SOPRANO

Simplified RS-232
Transceiver Schematics
(One of 8 Ports)

© EKF
ekf.com


5

GND


for RS-232 mode switches 1-8 must be set to off

ANSI/TIA
EIA-232


SP337 RS-232



3



7



4

1-9:
Micro-D